



## 102-442 Installation Guide

1. Install the new air filter (102-442) into the rubber intake boot noting that the bottom of the air filter should be against the end of rubber intake boot.



2. Tighten the air filter clamp enough so that the air filter does not rotate in the rubber intake boot. If the air filter rotates, tighten the clamp further until the air filter does not rotate. It is important not to over tighten the clamp, this could risk deformation to the air filter neck.



900-9942

