

## Toro Greensmaster 3100



PART NO.	DESCRIPTION	REPLACES
1. 100-533	Air Filter	Toro 108-3811
2. 100-131	Air Filter	Toro 92-0527
3. 100-743	Pre-Filter	Toro 272490S
4. 100-073	Air Filter	Briggs & Stratton 393957S
5. 100-685	Pre-Filter	Briggs & Stratton 271794S
6. 100-519	Air Filter	Toro 108-3833
7. 100-887	Air Filter	Briggs & Stratton 805113
8. 100-879	Pre-Filter	Briggs & Stratton 805267S
9. 230-160	Bearing	Toro 109842
10. 230-033	Bearing	Toro 109842
11. 215-285	Tapered Bearing Set	Toro 27-0960
12. 230-929	Tapered Roller Bearing Set	Toro 254-78

CONTINUED ON NEXT PAGE

**Toro Greensmaster 3100** (Cont.)



PART NO.	DESCRIPTION	REPLACES
13. 150-009	Recoil Starter Assembly	Briggs & Stratton 392102
14. 230-961	Bearing	Toro 251-347
15. 230-753	Bearing	Toro 93-2489
16. 248-030	True Blue Belt	Toro 1561
17. 295-089	Control Head	Briggs & Stratton 691028
18. 125-384	Fuel Cap	Toro 112-6120
19. 125-179	Fuel Cap	Toro 112-6120
20. 125-223	Fuel Cap	Briggs & Stratton 795027
21. 120-444	Fuel Filter	Toro 108-3831
22. 120-678	Fuel Filter	Toro 98-7612
23. 120-914	Fuel Filter	Toro 94-2690
24. 120-410	Fuel Filter	Toro 108-3831
25. 120-562	Fuel Filter	Toro 108-3854
26. 120-566	Fuel Filter Shop Pack (case of 25)	Toro 108-3854
27. 120-570	Fuel Filter Merchandiser	Toro 108-3854
28. 120-188	Fuel Filter	Toro 56-6360
29. 120-746	Fuel Filter Shop Pack (case of 25)	Toro 56-6360
30. 120-311	Fuel Filter Merchandiser	Briggs & Stratton 298090S
31. 120-114	Hose Clamp (case of 2)	Briggs & Stratton 791850
32. 120-224	Inline Fuel Shutoff Valve	Briggs & Stratton 698182
33. 520-441	Fuel Pump	Briggs & Stratton 808656
34. 520-590	Fuel Pump	Briggs & Stratton 808656
35. 475-454	Valve Cover Gasket	Briggs & Stratton 806039S
36. 160-668	Kenda Tire (18x9.50-8)	Toro 28-3680
37. 440-433	Solid State Module	Briggs & Stratton 799650
38. 440-450	Ignition Coil	Briggs & Stratton 845606
39. 430-009	Indak Ignition Key (case of 2)	Briggs & Stratton 691959
40. 430-950	Indak Ignition Switch	Toro 83-0020
41. 110-148	Muffler Deflector	Briggs & Stratton 795036

CONTINUED ON NEXT PAGE

**Toro Greensmaster 3100** (Cont.)


PART NO.	DESCRIPTION	REPLACES
42. 120-485	Oil Filter	Toro 107-7817
43. 120-483	Oil Filter Shop Pack (case of 12)	Toro 107-7817
44. 120-360	Oil Filter	Toro 108-3841
45. 120-345	Oil Filter	Toro 85-4930
46. 120-970	Oil Filter Shop Pack (case of 12)	Toro 85-4930
47. 125-334	Oil Seal	Briggs & Stratton 281370S
48. 515-015	Piston Std.	Briggs & Stratton 793214
49. 435-431	Starter Solenoid	Toro 111674
50. 435-032	Starter Solenoid	Toro 111674
51. 135-081	Spark Plug Boot	Briggs & Stratton 66538S
52. 135-008	Spark Plug Terminal	Briggs & Stratton 493880S
53. 130-526	Champion Spark Plug	Champion RC12YC
54. 130-069	Champion Spark Plug	Champion XC92YC
55. 130-276	NGK Spark Plug	NGK ZFR5F
56. 131-015	Torch Spark Plug	Torch K5RTC
57. 130-760	Torch Spark Plug Shop Pack (case of 100)	Torch K5RTC
58. 150-292	Starter Drive Gear	Briggs & Stratton 695708
59. 150-027	Starter Drive Gear Shop Pack (case of 25)	Briggs & Stratton 695708
60. 150-114	Starter Drive Kit	Briggs & Stratton 696540
61. 435-859	Starter Drive Kit	Briggs & Stratton 696541
62. 150-118	Starter Drive Kit	Briggs & Stratton 696540
63. 435-211	Starter Drive Kit	Briggs & Stratton 496881
64. 435-803	Starter Brush Retainer	Briggs & Stratton 691293
65. 150-175	Recoil Starter Assembly	Briggs & Stratton 808152
66. 140-020	Starter Handle	Briggs & Stratton 490652
67. 435-320	Mega-Fire Electric Starter	Briggs & Stratton 795121
68. 435-295	Mega-Fire Electric Starter	Briggs & Stratton 691564
69. 435-195	Voltage Regulator	Briggs & Stratton 845907
70. 435-061	Voltage Regulator	Briggs & Stratton 794360