

Toro Greensmaster 3150



PART NO.	DESCRIPTION	REPLACES
2. 100-743	Pre-Filter	Toro 272490S
3. 100-131	Air Filter	Toro 92-0527
1. 425-573	ATC Fuse (case of 5)	Toro 218-578
4. 230-929	Tapered Roller Bearing Set	Toro 254-78
5. 125-384	Fuel Cap	Toro 112-6120
6. 125-179	Fuel Cap	Toro 112-6120
7. 125-223	Fuel Cap	Briggs & Stratton 795027
8. 120-562	Fuel Filter	Toro 108-3854
9. 120-566	Fuel Filter Shop Pack (case of 25)	Toro 108-3854
10. 120-570	Fuel Filter Merchandiser	Toro 108-3854
11. 120-444	Fuel Filter	Toro 108-3831
12. 120-914	Fuel Filter	Toro 94-2690

CONTINUED ON NEXT PAGE

Toro Greensmaster 3150 (Cont.)



PART NO.	DESCRIPTION	REPLACES
13. 520-441	Fuel Pump	Briggs & Stratton 808656
14. 520-590	Fuel Pump	Briggs & Stratton 808656
15. 160-668	Kenda Tire (18x9.50-8)	Toro 28-3680
16. 175-505	Valve Stem #412	Toro 5108
17. 440-433	Solid State Module	Briggs & Stratton 799650
18. 435-435	Starter Solenoid	Toro 740207
19. 435-099	Starter Solenoid	Toro 740207
20. 430-009	Indak Ignition Key (case of 2)	Briggs & Stratton 691519
21. 430-334	Indak Ignition Switch	Toro 104-2541
22. 430-950	Indak Ignition Switch	Toro 83-0020
23. 430-457	Delta Seat Switch	Toro 92-6282
24. 120-485	Oil Filter	Toro 107-7817
25. 120-483	Oil Filter Shop Pack (case of 12)	Toro 107-7817
26. 135-081	Spark Plug Boot	Briggs & Stratton 66538S
27. 135-008	Spark Plug Terminal	Briggs & Stratton 493880S
28. 130-526	Champion Spark Plug	Champion RC12YC
29. 130-069	Champion Spark Plug	Champion XC92YC
30. 130-276	NGK Spark Plug	NGK ZFR5F
31. 131-015	Torch Spark Plug	Torch K5RTC
32. 130-760	Torch Spark Plug Shop Pack (case of 100)	Torch K5RTC
33. 435-295	Mega-Fire Electric Starter	Briggs & Stratton 691564
34. 435-195	Voltage Regulator	Briggs & Stratton 845907