


**Toro Groundsmaster 580D**


PART NO.	DESCRIPTION	REPLACES
1. 102-816	Air Filter	Toro 69-1900
2. 230-969	Bearing	Toro 108-9017
3. 215-285	Tapered Bearing Set	Toro 1-543508
4. 265-900	OEM Replacement Belt	Toro 93-8457
5. 120-444	Fuel Filter	Toro 108-3831
6. 120-678	Fuel Filter	Toro 98-7612
7. 120-410	Fuel Filter	Toro 108-3831
8. 302-624	Silver Streak Toothed Blade	Toro 69-6920-03
9. 345-156	Medium-lift Blade	Toro 69-6920-03
10. 430-954	Indak Ignition Switch	Toro 27-2360
11. 430-457	Delta Seat Switch	Toro 92-6282
12. 285-540	Quick Pin	Toro 3290-384
13. 175-505	Valve Stem #412	Toro 5108