

**Toro Groundsmaster 5900**



PART NO.	DESCRIPTION	REPLACES
1. 425-502	ATC Fuse (case of 5)	30 Amp
2. 425-536	ATC Fuse (case of 5)	15 Amp
3. 425-573	ATC Fuse (case of 5)	10 Amp
4. 230-969	Bearing	Toro 108-9017
5. 265-701	OEM Replacement Belt	Toro 112-7376
6. 265-731	OEM Replacement Belt	Toro 112-7377
7. 302-694	Silver Streak Toothed Blade	Toro 110-5948-03
8. 125-336	Fuel Tank Bushing	Toro 46-6560
9. 430-401	Delta PTO Switch	Toro 95-4108
10. 175-505	Valve Stem #412	Toro 5108
11. 210-018	Deck Wheel	Toro 29-4820