

Toro Sand Pro 5040



PART NO.	DESCRIPTION	REPLACES
1. 100-533	Air Filter	Toro 108-3811
2. 100-743	Pre-Filter	Toro 272490S
3. 100-131	Air Filter	Toro 92-0527
4. 425-536	ATC Fuse (case of 5)	Toro 109355
5. 425-573	ATC Fuse (case of 5)	Toro 218-578
6. 248-030	True Blue Belt	Toro 1561
7. 125-384	Fuel Cap	Toro 112-6120
8. 125-179	Fuel Cap	Toro 112-6120
9. 125-223	Fuel Cap	Briggs & Stratton 795027

CONTINUED ON NEXT PAGE

Toro Sand Pro 5040 (Cont.)



PART NO.	DESCRIPTION	REPLACES
10. 120-444	Fuel Filter	Toro 108-3831
11. 120-914	Fuel Filter	Toro 94-2690
12. 120-562	Fuel Filter	Toro 108-3854
13. 120-566	Fuel Filter Shop Pack (case of 25)	Toro 108-3854
14. 120-570	Fuel Filter Merchandiser	Toro 108-3854
15. 520-441	Fuel Pump	Kohler 24 393 16-S
16. 520-590	Fuel Pump	Kohler 24 393 16-S
17. 125-336	Fuel Tank Bushing	Toro 46-6560
18. 440-433	Solid State Module	Briggs & Stratton 799650
19. 120-485	Oil Filter	Toro 107-7817
20. 120-483	Oil Filter Shop Pack (case of 12)	Toro 107-7817
21. 120-818	Transmission Filter	Toro 54-0110
22. 130-526	Champion Spark Plug	Champion RC12YC
23. 130-069	Champion Spark Plug	Champion XC92YC
24. 130-276	NGK Spark Plug	NGK ZFR5F
25. 131-015	Torch Spark Plug	Torch K5RTC
26. 130-760	Torch Spark Plug Shop Pack (case of 100)	Torch K5RTC
27. 135-081	Spark Plug Boot	Briggs & Stratton 66538S
28. 135-008	Spark Plug Terminal	Briggs & Stratton 493880S
29. 435-295	Mega-Fire Electric Starter	Briggs & Stratton 691564
30. 435-435	Starter Solenoid	Toro 740207
31. 435-099	Starter Solenoid	Toro 740207
32. 430-950	Indak Ignition Switch	Toro 83-0020
33. 430-009	Indak Ignition Key (case of 2)	Indak
34. 430-413	Delta Safety Switch	Toro 82-2190
35. 175-505	Valve Stem #412	Toro 5108
36. 435-195	Voltage Regulator	Briggs & Stratton 845907