905-6780



Ignition Switch INSTRUCTION SHEET for 430-662

This ignition switch has a drain hole located on the threaded neck. This hole will permit water/moisture to enter the ignition switch if installed upside down.

If the switch is installed incorrectly (drain hole facing up) water cannot drain properly, ultimately failing the switch.



